


Systems Reference Library

IBM 2540 Component Description and Operating Procedures

This publication explains the operating principles, procedures, and controls of the IBM 2540 Card Read Punch. Special features for the 2540 are also discussed.

Refer to the SRL publication, IBM 2821 Control Unit, Form A24-3312, for information concerning the commands, status and sense indicators, and other programming considerations that affect the 2540.




This publication is a major revision, and obsoletes the previous edition, Form A21-9033-0. Restart procedures have been revised in several places, and other minor changes have been made throughout the manual.

Copies of this and other IBM publications can be obtained through IBM Branch Offices. Address comments concerning the content of this publication to: IBM Corporation, Product Publications, Dept. 245, Rochester, Minn. 55901

CONTENTS

5	IBM 2540 CARD READ PUNCH
5	Introduction
5	Operating Principles
5	Data-Mode 1
5	Reading
5	Punching
5	Stacker Selection
8	Special Features
8	Data-Mode 2
8	Punch Feed Read
9	51-Column Interchangeable Read Feed
9	Operator Controls
9	Reader Controls
10	Punch Controls
11	Common Indicator Lights
11	Operating and Restart Procedures
11	Initial Start
11	Restarts from Error Conditions
11	Jam Removal



IBM 2540 Card Read Punch

INTRODUCTION

The IBM 2540 Card Read Punch is an input-output device for IBM System/360 Models 30 and higher. Connection of the 2540 to a System/360 processing unit is made through an IBM 2821 Control Unit, Model 1, 4, or 5, attached to a multiplexor or selector channel. All data and control signals transferred between the processing unit and the 2540 pass through the 2821; buffers in the 2821 permit the transfer of data independent of the reading and punching speed of the 2540.

The 2540 has separate read and punch feeds, with maximum reading speed of 1000 cards per minute and maximum punching speed of 300 cards per minute. The punch hopper holds approximately 1350 cards; the read hopper and file-feed magazine hold approximately 3100 cards.

The five radial stackers of the 2540 are so controlled that three stackers serve each feed: stackers R1 and R2, at the right end of the stacker group, can receive cards from the read feed only; stackers P1 and P2, the leftmost stackers, can receive cards from the punch feed only; and the center stacker, RP3, can receive cards from both feeds. RP3 should not be used for both the reader and the punch at the same time. Each stacker holds approximately 1350 cards; cards can be removed from any stacker without interrupting operation of the 2540.

OPERATING PRINCIPLES

Data-Mode 1

The 2540, as well as all System/360 configurations, uses the EBCDI code (Extended Binary Coded Decimal Interchange code) for all operations in data-mode 1 (Figure 1). Information processed in data-mode 1 is checked for validity according to the rule, "Any combination of punches in a single card column is valid if it contains no more than one punch in rows 1-7."

Reading

The 2540 read operation requires three machine cycles. During the first cycle, the card moves from the hopper to the read-check station (Figure 2). During the second cycle, the card passes through the read-check station to the read station. During the second cycle, the read-check brushes read the

punches in the card and develop a hole count for each column. On the third cycle, the card passes through the read station to the pre-stacker station. Data read from the card during the third cycle enters the read buffer in the 2821, from where it will be passed to the channel in response to the next read instruction.

Also during the third cycle, a second hole count is developed by the read brushes for each column and compared to the hole count from the read-check station. Disagreement between the two counts results in a read-check.

Punching





The punch operation requires four machine cycles. During the first cycle, the card leaves the hopper and moves to the blank station (Figure 2). During the second cycle, the card moves past the blank station to the punch station.

Data from the punch buffer in the 2821 is punched into the card during the third cycle as the card moves row-by-row through the punch station, and a hole count of the data being punched is developed and stored for each column. During the fourth cycle, the card passes through the punch-check station, where the punch-check brushes read the card, and develop a second hole count for each column, comparing it to the hole count from the punch station. After punch checking, the card passes into the stacker area.

Stacker Selection

Read-stacker selection on the 2540 can be specified with the card-read instruction, or selection can be delayed until the program can evaluate the information read from the card and determine the appropriate stacker. There is no time limit for specifying the stacker selection, except that the select command must be given before, or with, the next Read command.

NOTE: If the 2540 Compatibility special feature is installed on the 2821, and the 2540 is operating in 2540 compatibility mode, stacker selection cannot be specified with the read instruction, but must be specified within six milliseconds after data from the card is passed to the channel.



- | | | |
|-----------------|-----------|------------|
| ① 12-0-1-8-9 | ⑥ 12 | ⑪ 0-2-8 |
| ② 12-11-1-8-9 | ⑦ 11 | ⑫ 0 |
| ③ 11-0-1-8-9 | ⑧ 12-11-0 | ⑬ 0-1 |
| ④ 12-11-0-1-8-9 | ⑨ 12-0 | ⑭ 11-0-1-9 |
| ⑤ No Punches | ⑩ 11-0 | ⑮ 12-11 |

Figure 1. EBCDIC Punching Configurations (Part 1 of 2)

CONTROL CHARACTERS

PF	Punch Off	BS	Backspace	PN	Punch On
HT	Horizontal Tab	IL	Idle	RS	Reader Stop
LC	Lower Case	BYP	Bypass	UC	Upper Case
DEL	Delete	LF	Line Feed	EOT	End of Transmission
RES	Restore	EOB	End of Block	SM	Set Mode
NL	New Line	PR	Prefix	SP	Space
SOS	Start of Significance	FS	Field Separator	DS	Digit Select

SPECIAL GRAPHIC CHARACTERS

¢	Cent)	Right Parenthesis	>	Greater-than
.	Period, Decimal Point	;	Semicolon	?	Question Mark
<	Less-than	¬	Logical Not	:	Colon
(Left Parenthesis	-	Minus, Hyphen	#	Number
+	Plus	/	Slash	@	At
	Vertical Bar, Logical OR	,	Comma	'	Prime, Apostrophe
&	Ampersand	%	Percent	=	Equal
!	Exclamation Point	_	Underscore	"	Quotation Mark
\$	Dollar	*	Asterisk		

Example	Type	Bit Pattern Bit Positions 01 23 4567	Hole Pattern	
			Zone Punches	Digit Punches
PF	Control Character	00 00 0100	12	4-9
%	Special Graphic	01 10 1100	0	4-9
R	Upper Case	11 01 1001	11	9
a	Lower Case	10 00 0001	12-0	1
	Control Character, function not yet assigned	00 11 0000	12-11-0	1-8-9

Note: Users can assign significance to those bit/punch configurations with no specified graphic character, but such assignments will not be supported by IBM.

Figure 1. EBCDIC Punching Configurations (Part 2 of 2)

Punch-stacker selection must be specified with the punch instruction. In 1400 Compatibility operations, however, the stacker selection in a punch instruction can be used to stack the card punched by

the previous punch instruction.

A punch-check overrides the stacker selection specified in any instruction, and sends the card to stacker P1.




Figure 2. Card Paths

SPECIAL FEATURES

Data-Mode 2

The Column-Binary special feature on the 2821 permits the 2540 to read and punch records in data-mode 2 (column-binary coding). Each of the 80 card columns can contain two characters in data-mode 2. The upper six positions in each column are assigned to an odd-numbered storage byte; the lower six positions are assigned to the next higher even-numbered byte (Figure 3). Because each character has just six bits, positions 0 and 1 of each 8-bit byte processed in data-mode 2 are set to zero.

Any combination of punches in a single column is valid in data-mode 2; validity checking in the 2540 read feed is suspended during data-mode 2 operation. Hole-count checking in both feeds is maintained.

Punch Feed Read

The PFR (Punch-Feed-Read) special feature consists of a set of 80 reading brushes installed in the blank station in the 2540 punch feed (see Figure 2). With PFR, the 2540 can process prepunched cards in the punch feed. Prepunched data is read, and can be sent to the processing unit; new information can be punched into the cards after they have been read. If the cards in the punch feed are not prepunched, the normal punch instructions can be used. If the cards are prepunched, the PFR instructions must be used, or punch-check errors will result.

Reading and punching in the punch feed are simultaneous: as data leaves the punch buffer and is punched row-by-row at the punch station, it is replaced by

data from the card at the punch-feed-read station. Because the data being read from the punch feed enters the punch buffer, separate files of cards can be read simultaneously, one file in each feed, by the 2540.

A hole count is developed for each column read at the punch feed-read station. To this count is added the hole count from the data punched into the card at the punch station, and the total count is verified at the punch-check station. For this reason, punching in prepunched columns is permissible with PFR, but such punching cannot repeat the prepunching. For example, punching an X-punch in a column that already contains a 2-punch is allowed; punching the letter K (X and 2 punches) into that column would repeat the 2-punch and would therefore cause a punch-check error.




Figure 3. Data Mode 2 Data Representation

51-Column Interchangeable Read Feed

The 51-Column Interchangeable Read Feed special feature makes possible the reading of either 80-column or 51-column cards by the 2540. The read hopper, the file-feed magazine, and stackers R1 and R2 are modified to permit the processing of either type of card; the capacities of these two stackers are reduced to approximately 800 cards, and maximum reading speed is reduced to 800 cards per minute for both types.

To change the 2540 from 80-column to 51-column card reading, the operator must place a guide rail at each side of the file-feed magazine to center the shorter cards on the magazine tray. He must also install side plates in the hopper to position the cards in the center of the hopper, and adjust stackers R1 and R2 by pulling forward the card guides at the rear of the stackers, and swinging down the adjustable card-pivot levers.

Returning to 80-column operation requires that the preceding steps be reversed. It is also sound practice to run a few 80-column cards through the feed before beginning operation after changing from the 51-column setup to ensure that all changes have been made correctly. This can be accomplished by loading a few cards into the hopper, entering them into the transport by pressing the reader start key, and performing a non-process-runout (NPRO) operation.

Because the 51-column cards are read in the center of the read feed, data from these cards enters positions 15-65 of the read buffer. Positions 1-14 of the buffer remain blank. At the programmer's option, data from the full 80 positions in the buffer, with positions 66-80 also blank, can be sent to the channel for each full-card record, or the full card can be read by terminating the data transfer after position 65.




Figure 4. Reader Controls and Common Indicator Lights

OPERATOR CONTROLS

The 2540 operator controls are of three types: those affecting only the reader (Figure 4), those affecting only the punch (Figure 5), and those that reflect conditions common to both feeds (see Figure 4).

Reader Controls

Start Key

The reader start key has three functions:

1. Pressing the start key feeds cards to all stations in the read feed, enters the data from the first card into the read buffer in the 2821, and places the reader in Ready status if the read feed is clear of cards, hopper or the file-feed magazine contains cards, power is on, and all interlocks are satisfied.
2. Pressing the start key, when the hopper is empty, the reader end-of-file light is off, and the hopper jogger gate is open causes an NPRO of any cards in the read feed into stacker R1.
3. Pressing the start key after clearing an error that required operator intervention, initiates any necessary feed cycles and places the reader in Ready status.




Figure 5. Punch Controls

Stop Key

Pressing the reader stop key halts card movement at the completion of the current operation, turns off the reader end-of-file light, and places the reader in Not Ready status.

End-of-File Key

Pressing the reader end-of-file key conditions the 2540 so that card feeding and reading will continue, after the read hopper is empty, until the last card has been read and stacked.

Lights

As an aid to the programmer and the operator in planning restart methods, the following descriptions of error lights include the associated 2540 sense indications.

Feed Stop (Sense-Bit 1, Intervention Required) turned on when the reader motor is stopped by a card jam, a misfeed, a read clutch failure, or a failure to receive a signal from the 2821 after a read cycle is completed. Feed Stop is turned off by the NPRO key.

Read Check (Sense-Bit 3, Equipment Check) signals the detection of a hole-count check, a parity check, an addressing error, or a translate check in the 2821 read buffer. Read Check is turned off by the next command.

Ready indicates that the reader is in Ready status.

Validity Check (Sense-Bit 4, Data Check) indicates that an invalid punch configuration (more than one punch in rows 1-7 of a single column) has occurred in a read or PFR data-mode 1 operation. Validity Check is turned off by the next command.

End-of-File indicates that the end-of-file key has been pressed, and that the end-of-file circuits are active. The end-of-file light goes out and the circuits are deactivated if the stop key is pressed, or if the last card has been stacked and an additional feed instruction, or read and feed instruction, has been received by the reader.

Punch Controls

Start Key

The punch start key has three functions:

1. Pressing the punch start key feeds cards into the punch and blank stations if the punch feed is clear of cards, the hopper contains cards, power is on, and all interlocks are satisfied. If PFR is installed, the contents of the first card enter the punch buffer in the 2821.
2. Pressing the punch start key with the hopper empty causes a NPRO of all cards in the punch feed into stacker P1. If PFR is installed, the punch end-of-file light must be off for a NPRO operation.
3. Pressing the punch start key after an error condition requiring operator intervention has been cleared initiates any necessary feed cycles, and restores the punch feed to Ready status.

Stop Key

Pressing the punch stop key halts card movement at the completion of the current operation, and places the punch in Not Ready status. If PFR is installed, pressing the punch stop key turns off the punch end-of-file light.

End-of-File Key

The end-of-file key is installed in the punch feed when the 2540 is equipped with the PFR special feature. Pressing the punch end-of-file key causes the 2540 to continue feeding and processing cards after the punch hopper is empty until the last card is read and stacked. This key should not be pressed for jobs that do not issue the PFR Read command for the last card of the file, because the 2540 will not punch the last record after the last card is read.

Lights

As an aid to the programmer and the operator in planning restart methods, the following descriptions of error lights include the associated 2540 sense indications.

Chips (Sense-Bit 1, Intervention Required) indicates that the chip box is either full, or improperly positioned.

Ready indicates that the punch is in Ready status.

Punch Check (Sense-Bit 3, Equipment Check) indicates the detection of a hole-count error, parity check,

addressing error, or translate check in the 2821 buffer. Punch Check is also turned on if these errors occur during a PFR Read operation. This indication is reset by the next command.

Feed Stop (Sense-Bit 1, Intervention Required) is turned on when the punch motor is stopped by a card jam, a misfeed, or a punch-clutch failure. Feed Stop is turned off by the NPRO key.

End-of-File (installed in the punch feed only when the 2540 is equipped with the special feature) PFR turns on when the punch end-of-file key has been pressed, activating the punch-feed end-of-file circuits. If the punch stop key is pressed, the punch end-of-file light will go out and the circuits will be deactivated.

Common Indicator Lights

Transport (Sense-Bit 1, Intervention Required) indicates a card jam in the transport area of the 2540. This light goes out when the jam is cleared and the covers are closed.

Power indicates that the 2540 is being supplied with dc power.

Stacker (Sense-Bit 1, Intervention Required) indicates that any one of the five stackers is filled.

Fuse indicates that a signal fuse in the 2540 has blown. A blown fuse must be replaced by a fuse of the same size. An IBM Customer Engineer should be notified whenever a fuse has blown, because this could indicate a malfunction in the 2540 circuitry.

OPERATING AND RESTART PROCEDURES

Initial Start

To begin operation with the 2540 reader:

1. Perform a NPRO operation by opening the jogger gate, emptying the hopper, and pressing the reader start key to ensure that no cards are left in the feed.
2. Load the desired cards into the hopper of the file-feed magazine, and close the jogger gate. Card decks less than one-inch thick should be placed directly in the hopper with the card weight; larger decks can be placed in the file-feed magazine.
3. Press the reader start key.

To begin operation with the 2540 punch:

1. Perform a NPRO operation by emptying the hopper and pressing the punch start key.

2. Load the desired cards into the punch hopper.
3. Press the punch start key.

Restarts from Error Conditions

The 2540 uses the flexible System/360 command set; therefore, different external error conditions can each require different restart procedures, depending on whether the 2540 operation is reading, punching, or PFR. If the program provides some programmed message to indicate the 2540 sense conditions, (type-out, printout, system console display, etc.) the operator can use this message to determine which specific restart procedure he should follow. To locate the error card for read-check and validity-check errors, the operator should be familiar with the type of processing used by the program: that is, whether the program is reading and stacking each card with a single command, or delaying the stacker selection until the data from the card is analyzed.

Figures 6 and 7 show the various 2540 error indications and appropriate restart procedures for standard operations, for PFR operations, and for 2540 Compatibility-mode operations. The procedures in Figure 7 assume that the I/O-Check-Stop switch on the system console is on. External indications and channel indications are included in both figures. The programmer should display the sense indications to the operator.

NOTE: The punch end-of-file key, installed as part of the 2540 Punch-Feed-Read special feature, should not be used when the 2540 is operating in 2540 Compatibility mode.

Jam Removal

The operator can gain access to the top of the read feed, transport and stacker area, and punch feed by raising the top covers of the 2540. He can remove the read-check brushes, the read brushes, the punch-check brushes, and the PFR brushes, as necessary, to free jammed cards (Figure 8).

If brushes must be removed, avoid contact between the brushes and any other part of the machine. Such contact can damage the brushes or blow a fuse. When replacing these brushes, the locking pins should be snapped into place before a restart is attempted. A series of reader checks or punch checks upon restarting could indicate damaged or improperly positioned brushes.

Jams in the punch unit could require the operator to open the front cover of the punch feed, crank the punch clutch to a setting between 335° and 350°, remove the plastic chip funnel, and lower and remove the punch die (Figure 9). The die has a handle shaped like an inverted T. The operator must turn this

Indications	Restart Procedures
<p>Reader Feed Stop Light (Only) Sense Bit 1--Intervention Required (Only)</p> <p>NOTE: If read check/bit 3 or validity check/bit 4 indications accompany feed stop/bit 1, follow procedure for read check or validity check.</p>	<ol style="list-style-type: none"> 1. Remove cards from stacker R1. 2. Open hopper jogger gate and remove cards from hopper. 3. Open covers and remove any jammed cards from read feed. Reconstruct any damaged cards. 4. With jogger gate still open, press reader start key to clear feed. 5. Remove cards just run out into stacker R1, place them and any reconstructed cards, in proper sequence, ahead of cards removed from hopper, and replace this deck in hopper or ahead of cards in file feed magazine. 6. Close jogger gate. 7. Press reader start key.
<p>Reader Feed Stop Light Read Check Light Sense Bit 1--Intervention Required (Only)</p>	<p>This combination of error indications accompanies a 2540 read clutch failure; there may be cards in stacker R1 that have not been read. Restart the job from the last checkpoint.</p>
<p>Read Check Light Sense Bit 3--Equipment Check (If card is read and stacked with single command.)</p>	<ol style="list-style-type: none"> 1. Remove cards from stacker R1. Determine (perhaps with aid from programmed message) which was last card read into processing unit, and correct any off-registration punching in it. Place this corrected card in stacker R1. 2. Open jogger gate and remove cards from hopper. 3. With jogger gate open, press reader start key to clear read feed. 4. Remove cards from stacker R1 and place them ahead of cards removed from hopper. Place this deck in hopper or ahead of cards in file feed magazine. 5. Close jogger gate. 6. Press reader start key.
<p>Read Check Light Sense Bit 3--Equipment Check (If stacker selection is delayed.)</p>	<ol style="list-style-type: none"> 1. Remove cards from stacker R1. 2. Follow steps 2-6 of preceding procedure, correcting any off-registration punching in first card run out into stacker R1.
<p>Validity Check Light Sense Bit 4--Data Check (If card is read and stacked with single command.)</p>	<ol style="list-style-type: none"> 1. Remove cards from stacker R1. Determine (perhaps with aid from programmed message) which was last card read into processing unit (this card may be in another stacker) and correct any errors in this card. Place the corrected card in stacker R1. 2. Open jogger gate and remove cards from hopper. 3. With jogger gate open, press reader start key to clear read feed. 4. Remove cards from stacker R1 and place them ahead of cards removed from hopper. Place this deck in hopper or ahead of cards in file feed magazine. 5. Close jogger gate. 6. Press reader start key.
<p>Validity Check Light Sense Bit 4--Data Check (If stacker selection is delayed.)</p>	<ol style="list-style-type: none"> 1. Remove cards from stacker R1. 2. Open jogger gate and remove cards from hopper. 3. With jogger gate open, press reader start key to clear read feed. 4. Locate and correct invalid character(s) in first card in stacker R1. 5. Place corrected card ahead of cards in stacker R1. Place all cards in stacker R1 ahead of cards removed from hopper. Place this deck in hopper or ahead of cards in file feed magazine. 6. Close jogger gate. 7. Press reader start key.

Figure 6. Restart Procedures - Standard and PFR Operation (Part 1 of 3)

Indications	Restart Procedures
Validity Check Light Punch Check Light Sense Bit 3--Equipment Check Sense Bit 4--Data Check (If 2540 is performing PFR read operation.)	<ol style="list-style-type: none"> 1. Remove card from punch hopper. 2. Press punch start key to clear punch feed. 3. Remove last three cards from stacker P1. 4. The first of these three cards may have to be reconstructed because it has been read and punched but not punch checked. 5. The second card caused the validity check. Correct it as necessary. 6. Place these three cards, after any necessary corrections, in front of the cards removed from the hopper. Place this deck in the hopper. 7. Press the punch start key. 8. Reconstruct internal data in the system as necessary to restart at the Start I/O instruction that caused the reading of the first card run out of the punch feed in step 3. <p>NOTE: In some programs, reconstruction of internal data may not be provided for. In that case, restart the job from the last checkpoint.</p>
Punch Feed Stop Light (Only) Sense Bit 1--Intervention Required (Only) (If the 2540 is not performing PFR operations.)	<ol style="list-style-type: none"> 1. Remove cards from stacker P1. 2. Remove cards from hopper. 3. Open covers and remove any jammed cards from punch feed. 4. Press punch start key to clear punch feed. 5. Discard last card punched (2540 will repunch this card automatically). 6. Replace blank cards in hopper and press punch start key. Last card will be repunched automatically and 2540 enters ready status.
Punch Feed Stop Light (Only) Sense Bit 1--Intervention Required (Only) (If 2540 is performing PFR operation.)	<ol style="list-style-type: none"> 1. Remove cards from stacker P1. 2. Remove cards from hopper. 3. Open covers and remove any jammed cards from punch feed. Press punch start key to clear feed. 4. Any card removed or run out from between punch station and punch check brushes should be reconstructed, because it has been punched but not punch checked. 5. Place reconstructed cards and cards run out into stacker P1 in proper sequence ahead of cards removed from hopper, and place this deck in hopper. 6. Press punch start key. 7. Reconstruct internal data in the system as necessary to restart at the Start I/O instruction that caused the first card removed or run out to be read at the PFR station. <p>NOTE: In some programs, reconstruction of internal data may not be provided for. In that case, restart the job from the last checkpoint.</p>
Punch Check Light Sense Bit 3--Equipment Check (If 2540 is not performing PFR operation and is using stacker P1.)	<ol style="list-style-type: none"> 1. Remove cards from hopper. 2. Press punch start key to clear punch feed. 3. Remove last four cards from stacker P1. The last two cards are blank; the first two should be discarded. 4. Replace blank cards and cards removed from hopper in hopper. 5. Reconstruct internal data in the system as necessary to restart at the Start I/O instruction that caused the first card removed from stacker P1 to be punched. <p>NOTE: In some programs, reconstruction of internal data may not be provided for. In that case, restart the job from the last checkpoint.</p>

Figure 6. Restart Procedures - Standard and PFR Operation (Part 2 of 3)

Indications	Restart Procedures
Punch Check Light Sense Bit 3--Equipment Check (If 2540 is not performing PFR operation and is not using stacker P1.)	<ol style="list-style-type: none"> 1. Examine and correct, if necessary, error card, which is last card in stacker P1. (2540 automatically routes error cards to stacker P1.) 2. Place this card in appropriate stacker. 3. Press punch start key. 4. The 2540 will force the card following the error card into stacker P1, also. Place this card in the appropriate stacker. NOTE: Because the error card and the card following it are both directed to stacker P1, the program can correct a non-PFR punch check without operator intervention by repunching both cards and directing them to appropriate stackers. The operator can then discard all cards in stacker P1 at the end of the job.
Punch Check Light Sense Bit 3--Equipment Check (If 2540 is performing PFR operation.)	<ol style="list-style-type: none"> 1. Remove cards from punch hopper. 2. Press punch start key to clear feed. 3. Remove last four cards from stacker P1. The last two cards are correct; pre-punching in the first two must be reconstructed. 4. Place the two reconstructed cards, the two correct cards, and the cards removed from the hopper, in that sequence, in the hopper. 5. Reconstruct internal data in the system as necessary to restart at the Start I/O instruction that caused the first reconstructed card to be read at the PFR station. NOTE: In some programs, reconstruction of internal data may not be provided for. In that case, restart the job from the last checkpoint.

Figure 6. Restart Procedures - Standard and PFR Operation (Part 3 of 3)

handle clockwise until the lock at the top of the die is released, and, if necessary, trip the ejection trigger on the handle to remove the die from the machine.

When all cards and card fragments have been removed from the punch unit, the operator replaces the die by pushing it up into the punch unit, and turning the handle counterclockwise. The die is improperly seated if a light tug on the handle causes it to fall.

Indications	Restart Procedures
Reader Feed Stop Light (Only) System Console Main Storage Data Register (MSDR) Display: 4F	<ol style="list-style-type: none"> 1. Remove cards from stacker R1. 2. Open jogger gate and remove cards from read hopper. 3. Open covers and remove any jammed cards from read feed. 4. With jogger gate still open, press reader start key to clear feed. Any damaged cards must be reconstructed. 5. Remove cards just run out into stacker R1. Place them and any reconstructed cards, in proper sequence, ahead of cards removed from hopper, and place this deck in hopper or ahead of cards in file feed magazine. 6. Close jogger gate. 7. Press reader start key. 8. Press system console start key.
Reader Feed Stop Light Read Check Light System Console MSDR Display: 3F (If there is no card jam in the 2540 read feed.)	This combination of error indications accompanies a 2540 read clutch failure; there may be cards in stacker R1 that have not been read. Restart the job from the last checkpoint.
Reader Feed Stop Light Read Check Light System Console MSDR Display: 3F (If there is a jam in the 2540 read feed.)	Follow the procedure for read check or validity check (the next procedure in this chart).
System Console MSDR Display: 3F (Read check or validity check has occurred, but the light has been turned off.) NOTE: This same indication can occur for PFR operation; see that procedure later in this chart if appropriate.	<ol style="list-style-type: none"> 1. The last card in stacker R1 is error card. Correct it. 2. Open jogger gate and remove cards from hopper. 3. With jogger gate open, press reader start key to clear feed. 4. Place corrected card ahead of the three cards just run out into stacker R1. Place these four cards ahead of the cards removed from the hopper, and place this deck in the hopper or ahead of the cards in the file feed magazine. 5. Close jogger gate. 6. Press reader start key. 7. Press system console start key.
Punch Feed Stop Light (Only) System Console MSDR Display: 5F (If 2540 is not performing PFR operation.)	<ol style="list-style-type: none"> 1. Remove cards from stacker P1. 2. Remove cards from punch hopper. 3. Open covers and remove any jammed cards from punch feed. 4. Press punch start key to clear feed. 5. Discard last card punched (2540 will repunch this card automatically). 6. Replace blank cards in hopper and press punch start key. Last card will be repunched. 7. Press system console start key.
Punch Check Light (Punch feed stop light may be on or off.) System Console MSDR Display: 5F (If 2540 is not performing PFR operation.)	<ol style="list-style-type: none"> 1. The last card in stacker P1 caused the punch check. Correct it as necessary. Place corrected card in appropriate stacker. 2. Press system console start key.

Figure 7. Restart Procedures - 2540 Compatibility Operation (Part 1 of 2)

Indications	Restart Procedures
<p>System Console MSDR Display: 3F Punch Check Light and Validity Check Light may be on or off</p> <p>(If 2540 is performing PFR operation.)</p>	<ol style="list-style-type: none"> 1. Remove cards from punch hopper. 2. Press punch start key to clear feed. 3. Remove last three cards from stacker P1. 4. The first of these three cards must be reconstructed because it has been read and punched but not punch checked. 5. The second card caused the error; correct it as necessary. 6. Place reconstructed card 1, corrected card 2, and card 3 in front of the cards removed from the hopper. At the front of this deck place a readily-identifiable blank card, and place this deck in the hopper. 7. Reconstruct internal data in the system as necessary to restart at the instruction that caused card 1 (see steps 4-6) to be read at the PFR station. NOTE: In some programs, reconstruction of internal data may not be provided for. In that case, restart the program from the last checkpoint. Be sure that the readily-identifiable blank card is the first card in the hopper. 8. Set the system console process switch at SINGLE CYCLE. 9. Set address 10FF in switches F, G, H, and J on the system console. 10. Press the system reset key. 11. Press ROAR reset key. 12. Press system console start key. 13. Set system console process switch at PROCESS. 14. Press 2540 punch start key. 15. At system console, perform Set IC function to address appropriate instruction. See <u>Operator's Guide</u> for the appropriate system. 16. Press system console start key to resume processing. 17. Remove readily-identifiable blank card inserted in step 6 when it is stacked. This card may now be punched; if it is, discard it.
<p>Punch Feed Stop Light (Only) System Console MSDR Display: 5F</p> <p>(If 2540 is performing PFR operation.)</p>	<ol style="list-style-type: none"> 1. Remove cards from stacker P1. 2. Remove cards from punch hopper. 3. Open covers and remove any jammed cards from punch feed. 4. Press punch start key to clear feed. 5. Any cards removed or run out from between punch station and punch check brushes have been punched but not punch checked. Pre-punching in these cards should be reconstructed. 6. Place any reconstructed cards and cards run out into stacker P1 in proper sequence ahead of cards removed from hopper. Place a readily-identifiable blank card ahead of this deck and place deck in hopper. 7. Perform steps 7-17 of preceding procedure in this chart.
<p>Punch Check Light (Punch feed stop light may be on or off.)</p> <p>(If 2540 is performing PFR operation.)</p>	<ol style="list-style-type: none"> 1. Remove cards from punch hopper. 2. If punch feed stop light is on, open covers and remove any jammed cards from punch feed. Correct any damaged cards. 3. Press punch start key to clear feed. 4. Of the last four cards to enter the 2540 punch feed, the last two are correct and pre-punching in the first two must be reconstructed. 5. Place a readily-identifiable blank card, the two reconstructed cards, the two correct cards, and the cards removed from the hopper in the hopper. 6. Perform steps 7-17 of PFR punch/validity check procedure (two procedures back in this chart).

Figure 7. Restart Procedures - 2540 Compatibility Operation (Part 2 of 2)




Figure 8. Access to Transport




Figure 9. Access to Punch Feed

READER'S COMMENT FORM

IBM 2540 Component Description
and Operating Procedures

Form A21-9033-1

- Your comments, accompanied by answers to the following questions, help us produce better publications for your use. If your answer to a question is "No" or requires qualification, please explain in the space provided below. Comments and suggestions become the property of IBM.

- | | Yes | No |
|--|---|--------------------------|
| ● Does this publication meet your needs? | <input type="checkbox"/> | <input type="checkbox"/> |
| ● Did you find the material: | | |
| Easy to read and understand? | <input type="checkbox"/> | <input type="checkbox"/> |
| Organized for convenient use? | <input type="checkbox"/> | <input type="checkbox"/> |
| Complete? | <input type="checkbox"/> | <input type="checkbox"/> |
| Well illustrated? | <input type="checkbox"/> | <input type="checkbox"/> |
| Written for your technical level? | <input type="checkbox"/> | <input type="checkbox"/> |
| ● What is your occupation? _____ | | |
| ● How do you use this publication? | | |
| As an introduction to the subject? <input type="checkbox"/> | As an instructor in a class? <input type="checkbox"/> | |
| For advanced knowledge of the subject? <input type="checkbox"/> | As a student in a class? <input type="checkbox"/> | |
| For information about operating procedures? <input type="checkbox"/> | As a reference manual? <input type="checkbox"/> | |
| Other _____ | | |
| ● Please give specific page and line references with your comments when appropriate.
If you wish a reply, be sure to include your name and address. | | |

COMMENTS:

- Thank you for your cooperation. No postage necessary if mailed in the U.S.A.

fold

fold

FIRST CLASS
PERMIT NO. 387
ROCHESTER, MINN.

BUSINESS REPLY MAIL

NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES

POSTAGE WILL BE PAID BY . . .

IBM Corporation
Systems Development Division
Development Laboratory
Rochester, Minnesota 55901

Attention: Product Publications, Dept. 245

fold

fold

IBM

International Business Machines Corporation
Data Processing Division
112 East Post Road, White Plains, N.Y. 10601



International Business Machines Corporation
Data Processing Division
112 East Post Road, White Plains, N.Y. 10601